

# Eclipse Touch Decoder

The Eclipse Touch MWD decoder system pioneers a new generation of performance and execution. As the market-leading decoder, it has been deployed on hundreds of rigs across North America and is the number one choice for its unmatched reliability and performance.

The system automatically deploys a series of proprietary algorithms to continuously and intelligently apply more than 100 filter combinations to ensure that even the weakest and noisiest signals are decoded. This fully automated filter application completely eliminates the need for user interaction, thereby maximizing decode success rates and eliminating the need for user training and support.


The Eclipse Touch software can be loaded onto any standard PC and provides a highly intuitive user interface designed with a complete focus on ease of use.

## Configurable to Meet Exact User Needs

Options available to either supply all required components or to allow use of existing hardware:

**Full System** - Decoder hardware is installed in an intrinsically safe Rig Floor Display [RFD] running Eclipse Touch software. Pressure Transducer and cable connect to the RFD. Radio connection to the MWD Cabin PC.

**eDAQ Alternative** - Decoder presented as an intrinsically safe standalone unit with SPP input and USB output to any machine running Eclipse Touch software. User can use existing or local hardware to complete the system.



## Features & Benefits

### Manual Decode

Manual selection of missed synchronization pulses allows automatic reprocessing and minimizes risk of missed data and removes requirement to cycle pumps to regain synch.

### WITS Connectivity

Fully configurable WITS in and out allows connection to standard rig systems or logging packages.

### Wireless Connection

Simple PC-to-PC communication from rig floor to MWD cabin through off-the-shelf radio communication is standard.

### Remote Operation Ready

Easily configured and reliable external communication makes remote operation of the system a reality.

### Signal Replay

Input pressure signal is automatically recorded and can be replayed at any time for diagnostic purposes.

Interface Specifications	
Variable	Specification
Power Input	100-240 VAC, 50/60 HZ
Data Connection	USB-A
SPP Connection	19-pin Amphenol 4-20 mA





## LOCATIONS



## USA

### BLACK DIAMOND CORPORATE

7906 N. Houston Parkway W  
Suite 200  
Houston , TX 77064  
1.281.443.0062

### BLACK DIAMOND BROUSSARD

1173 Old Spanish Trail, Hwy 182 N  
Broussard, LA 70518  
1.337.359.1994

### BLACK DIAMOND CONROE

4205 FM 1485  
Conroe, TX 77306  
1.936.441.1480

### BLACK DIAMOND MWD

2418 N Frazier Street #100  
Conroe, TX 77303  
1.936.202.2889

### BLACK DIAMOND WEST TEXAS

3510 N. County Rd 1148  
Midland, TX 79705  
1.432.689.0076

## CANADA

### BLACK DIAMOND EDMONTON

Wenzel Downhole Tools  
3115 - 93 Street NW  
Edmonton, AB T6N 1LY  
1.780.440.4220

## GUYANA

### BLACK DIAMOND GEORGETOWN

Plantation "A"  
Houston District  
East Bank Demerara  
Georgetown, Guyana

## MEXICO

### BLACK DIAMOND VILLAHERMOSA

Avenida San Lucas Manzana 2 Bodega 3 y 4  
Parque Logistico Industrial Tabasco  
Rancheria Anacleto Canabal 4ta. Seccion.  
Centrol, Tabasco C.P. 86287  
+52 993 688 8579

### BLACK DIAMOND TAMPICO

Carretera federal 20 de Noviembre km 18.7  
Congregacion Anahuac  
Pueblo Viejo, Ver., C.P. 92035  
+52 993 688 8579

## MIDDLE EAST

### BLACK DIAMOND ABU DHABI

Wenzel Downhole Tools  
Al Markaz Industrial Area  
Waha Land, LT01 B25-32  
Abu Dhabi, U.A.E.  
+971 2 585 2800